


USER MANUAL

EDGE



Thank you for purchasing an Arcsound product!

To ensure the best experience, please take a moment to read through this product manual carefully before use. Pay close attention to all warnings and follow the instructions provided. Keep the manual in a safe and easily accessible location for future reference.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Winn Scandinavia is under license. Other trademarks and trade names are those of their respective owners.



EDGE

SAFETY INFORMATION

For your safety and to ensure optimal performance, please observe the following precautions:

Battery Lifespan Protection:

To maintain the battery's health, ensure that you fully charge the EDGE at least once every 3 months. Keep in mind that battery life may vary based on usage patterns and environmental factors.

IPX6 Rating – Waterproof and Dustproof:

The EDGE is rated IPX6 for water and dust resistance, meaning it can withstand 100 liters of water sprayed onto it for 3 minutes at a pressure of 100 kPa.

Liquid Exposure Warning:

Never expose the EDGE to liquids while it's connected to a cable. Additionally, avoid getting the speaker wet while charging, as this could result in permanent damage to both the speaker and its power source.

Impact of Chemicals and Saltwater:

Exposure to chemicals and salt from pool or ocean water can weaken the waterproof seals and damage the connector surface over time. Always rinse the EDGE with fresh water after exposure to these elements to prevent damage.

Charging After Liquid Exposure:

If the EDGE has been exposed to liquid, allow it to dry completely and ensure it is clean before charging. Charging while the speaker is wet could cause irreversible damage.

External Adapter Compatibility:

When using an external adapter, ensure that the output voltage and current do not exceed 5V/3A to avoid damaging the speaker.




CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



EDGE

WHAT'S INCLUDED



Bluetooth speaker




Quick start manual



USB-C charging cable

CONTROLS (FRONT)




SPEAKERPHONE
PLAY / PAUSE
🔊 / ⏸ / 🔊

- The default volume is set to 30% when the speaker is turned on.
- To skip to the next or previous song, press and hold the + or - button.
- Press and hold the **Play/Pause** button to disconnect Bluetooth.
- The speaker will automatically power off if not used for +20 min.





EDGE

CONTROLS (BACK)



BLUETOOTH FUNCTION



- 1 Hold the Button for 3 Seconds to Power On / Off
- 2 Choose **Bluetooth mode** by pressing the On / Off button
- 3 Open the Bluetooth settings on your mobile device and select **"EDGE"**




EDGE

SPEAKER PHONE

EDGE features a built-in microphone, hands-free solution. Thanks to the noise and echo cancelling function, you can now take crystal clear conference calls.



AUX IN




When you plug the 3.5mm audio cable into the speaker, it will automatically switch to line-in playback mode.

EDGE

TRUE WIRELESS STEREO

Pair 2 Arcsound EDGE speakers for an enhanced audio experience.



Power on both speakers, then press and hold the + and - buttons simultaneously to enter True Wireless Stereo (TWS) mode. **Note:**

- A) The next time you use both EDGE speakers, they'll automatically pair in True Wireless Stereo (TWS) mode.
- B) To disconnect from TWS mode, short press the + and - buttons simultaneously on either speaker. A voice prompt will notify you of the disconnection.

LED INDICATION

Status	LED indication
Working mode	Blue light glowing
Pairing mode	Blue light blinking
Charging	Red light glowing
Fully charged	Green light glowing

EDGE

SPECIFICATIONS

Product model	EDGE
Drivers	Woofer: 2" (55mm) - 2pcs Tweeter: 1" (25mm) - 2pcs
Bass enhancers	Passive Radiators (62mm) - 2pcs
Bluetooth version (chip)	MV5.3 (MV BP1048B2)
Output	40W (15Wx2 + 5Wx2)
Frequency response	66Hz - 21kHz
S/N (signal to noise ratio)	75dB
Battery type	Li-ion battery 7.4V 2500mAh 18.5Wh
Battery charging time	3 hours (5V/2A)
Playing time	Up to 10 hours*
Cabel type	USB-C charging cable
Cabel length	1m
Bluetooth profile	A2DP 1.3, AVRCP 1.6, HFP 1.6
BT transmitter freq. range	2402 MHz - 2480 MHz
BT transmitter power	+8dBm(EIRP)
BT transmitter modulation	GFSK, π/4 DQPSK, 8DPSK
Functions	BT / Aux in / TWS / Handsfree / Stadium Sound (on/off) / Pulse lights (on/off)
Product size (WxHxD)	84x220x84mm
Net weight	940g
Packaging size (WxHxD)	231x114x112mm
Gross weight	1142g
Operation temperature	MAX 45°C

* Dependent on volume and audio content

Arcsound is a trademark by Winn Scandinavia AB

Winn Scandinavia AB | Idrottsvägen 37, 70232 Örebro, Sweden
www.winnscandinavia.com

Winn Scandinavia AB reserves for possible typos, factual or numeric errors that may have been printed on any material or other included accessories.

EDGE

EDGE